

Respirable Dust Sampler Make SLBT Model SI-1693 Origin India



Specifications

- **Particle Collection:** The sampler serves as particle collector that collects the particles less than 10 microns on filter paper and bigger than 10 microns in a sampling bottle with the helps of a cyclone separator.
- **Bower Motor:** The sampler features bower motor instead of high-speed blower. This is a brushless and noiseless motor with no carbon brushes.
- **Programmable Timer & Relay:** The sampler possess programmable relay that helps in setting ON time and protects the motor in case of high or low voltage conditions.