

Digital Water Level Recorder Make SLBT Model SL-1738 Origin India



Specification

The **Digital Water Level Indicator** consists of a cable reel of not less than 30 meters, 40 meters, 60 meters, 90 meters and 150 meters long and two insulated wire bared at the contact which passes through a weighed probe of any suitable material. The Digital Water Level Indicator has complete cable reel carrying case, battery operated indicator unit, a spool with slip rings and bushes connecting the free ends of the insulated wire to the indicator. The reading is taken to the accuracy of 5 mm by measuring tape. We are a preferential choice for procuring high performing and quality Digital Water Level Indicator.