

Constant current discharge kit Make SLBT Model SL-1804 Origin India



Product Description

Constant Current Discharger is designed to discharge battery at a constant current. The set current is maintained within +/- 1% irrespective of the falling or raising voltage. The discharger may also be used as a constant load or with a variable voltage as a constant current source. Several units can be connected in parallel in order to increase the current requirement. The equipment is protected against short circuit, over voltage, over load etc.

- Discharges the battery at constant current
- Along with rectifier charges the battery at constant current
- Keeps the current constant irrespective of voltage fluctuations
- The set accuracy of current is within +/- 1%
- For higher current no. of units can be connected in parallel
- Protected against Reverse polarity, Short Circuit, Overload etc.